TEXTURIZING BLOW OUT STYLING PRODUCT

Hair Care

FORMULA#: 84-17-4

Lightweight styling cream that provides thermal protection, shine, and frizz control.

Application: Apply one to two pumps in hands and rub together, disperse evenly over damp hair, and blowdry with a round brush or heat style as desired.

HIGHLIGHTED INGREDIENTS

| INGREDIENT | FUNCTION |
|----------------------------|---|
| INDOPOL [®] H-100 | Uniquely versatile liquid polybutene polymer with a honey-like consistency and excellent film forming capabilities. |
| PANALANE [®] L-2E | It provides excellent spreadability with a smooth, non-greasy feel often found with other traditional ester emollients. |
| SILKFLO [®] 362 | Light, silky emollient that provides moisturization and has non-oily feel and great spreadability. Can be used as a dispersing agent for pigments. |
| PELLICER [®] L-30 | Peptide-like, plant-derived, multifunctional active ingredient. It has excellent surface-active properties and functions in emulsification and dispersion at very low use levels. Its ceramide-like Gemini structure also gives it a high affinity to skin and hair, providing moisturizing and damage repair properties. |
| BIOGENIC CAFFEINE-210-WS | Encapsulated and stabilized form of caffeine. Enables high concentrations in aqueous formulations without recrystallization. Helps increase appearance of hair density. |
| BIOGENIC ADENOSINE-30 | Water soluble encapsulates Adenosine with an active concentration of 25-35%. Helps restore hair vitality. |
| LIPIDURE® C | Active cationic, biocompatible polymer with excellent moisture retention properties. It acts by smoothing hair cuticles, to restore the strength of damaged hair and to reduce static electricity |
| D-PANTHENOL 75% | A more stable version of pantothenic acid (Vitamin B5). D-Panthenol gives good moisturizing and anti-inflammatory properties. It is a good humectant for hair, and spreads evenly making hair easier to comb. |

FORMULATION

| PHASE | TRADE NAME | INCI NAME | SUPPLIER | % W/W |
|-------|--|--|--|----------|
| | DI Water | Water (Aqua) | | 70.60 |
| | Sodium Phytate Sodiur | Sodium Phytate | | 0.05 |
| A | Citric Acid Solution 10% | Water (and)Citric Acid | | 0.35 |
| | Styleze™ ES-Dura | Guar Hydroxypropyltrimonium Chloride | Ashland | 1.00 |
| | SILKFLO [®] 362 | Hydrogenated Didecene | Presperse | 1.00 |
| В | Natrosol™ 250 HHR Hydroxyethylcellulose, PC Grade | Hydroxyethylcellulose | Ashland | 0.75 |
| С | SymSave® H | Hydroxyacetaphenone | Symrise | 0.30 |
| | Cetearyl Alcohol | Cetearyl Alcohol | Protameen | 1.50 |
| | Glyceryl Stearate | Glyceryl Stearate | Ashland Presperse Ashland Symrise Protameen Jeen Inolex Presperse | 0.50 |
| D | ProCondition™ 22 | Brassicamidopropyl Dimethylamine | Inolex | 2.50 |
| | INDOPOL® H-100 | Polybutene | Protameen 1 Jeen (Inolex 2 Presperse 2 | 2.00 |
| | PANALANE® L-2E | Hydrogenated Polyisobutene | Presperse | 3.00 |
| E | | Water (and) Polyquaternium-64 (and) Phenoxyethanol | Presperse | 2.00 |

Confidentiality Notice & Disclaimer: This presentation contains proprietary and confidential information for review only by the intended audience of the presentation and solely for the purpose of assessing whether the presenter and intended recipient to this presentation desire to enter into a business arrangement. If you are not the intended recipient of this presentation, you are hereby notified that the review, use, disclosure, distribution, or copying of this confidential and proprietary information is prohibited. If you have received this presentation in error, please notify the sender immediately and delete/destroy any and all copies. Additionally, the presenter cannot guarantee the accuracy of the data found within the presentation. The recipient of this presentation should make their own independent assessment using available scientific data and following all relevant legal and regulatory guidelines.



Visit us at www.presperse.com or email us at <u>info@presperse.com</u> for more information or product samples.

| I | D | L |)(| \sim |)(| CI | F |) | | D |) | F | |
|---|---|---|----|--------|----|----|---|---|--|---|---|---|--|
| | | | | | | | | | | | | | |

| PHASE | TRADE NAME | INCI NAME | SUPPLIER | % W/W |
|-------|----------------------------|--|-----------|----------|
| | BIOGENIC CAFFEINE-210-WS | Caffeine (and) Maltodextrin (and) Xanthan Gum (and) Hydroxyethylcellulose (and) Salicylic Acid (and) Phenoxyethanol | Presperse | 1.50 |
| E | BIOGENIC ADENOSINE-30 | Isoniacinamide (and) Adenosine (and) Cyclodextrin (and) Hydroxypropyl Cyclodextrin (and) Disodium EDTA | Presperse | 4.00 |
| | D-PANTHENOL 75% | Panthenol (and) Water (and) Citric Acid | Presperse | 2.00 |
| | PELLICER [®] L-30 | Water (and) Sodium Dilauramidoglutamide Lysine | Presperse | 0.20 |
| | SYMDIOL® 68 | 1,2-Hexanediol (and) Caprylyl Glycol | Symrise | 0.50 |
| F | CITRIC ACID SOLUTION 10% | Water (and)Citric Acid | | 6.25 |

notified that the navies imperfised of a distribution of power and this feature intradad an an and the provided the feature of the presentation in error, please notify the sender immediately and delete/destroy any and all copies. Additionally, the presented an manual to present a distribution of this presentation should make Let's Make Beauty Together™

their own independent assessment using available scientific data and following all relevant legal and regulatory guidelines. 4. In a separate beaker heat to 80°C and mix all ingredients in Phase D together until uniform.

Visit us at www.presperse.com or email us at info@presperse.com for more information or product samples.

Form-0194 Formulation Template, Effective Date 06/02/2023

TEXTURIZING BLOW OUT STYLING PRODUCT

- 5. Add Phase D to ABC mixture. Once batch appears unform and is cooled to 40°C add Phase E ingredients.
- 6. pH will be over 7.5. Add citric acid solution until batch is below 5.5. Product will become whiter and stabilize.

SPECIFICATIONS

Appearance: White lotion pH = 5.48 Viscosity = TBA

Confidentiality Notice & Disclaimer: This presentation contains proprietary and confidential information for review only by the intended audience of the presentation and solely for the purpose of assessing whether the presenter and intended recipient to this presentation desire to enter into a business arrangement. If you are not the intended recipient of this presentation, you are hereby notified that the review, use, disclosure, distribution, or copying of this confidential and proprietary information is prohibited. If you have received this presentation in error, please notify the sender immediately and delete/destroy any and all copies. Additionally, the presenter cannot guarantee the accuracy of the data found within the presentation. The recipient of this presentation should make their own independent assessment using available scientific data and following all relevant legal and regulatory guidelines.



Visit us at www.presperse.com or email us at <u>info@presperse.com</u> for more information or product samples.